

**Vauxhall Vivaro B 08/2014 >> 08/2019**  
**Renault Trafic 08/2014 >>**  
**Fiat Talento 07/2016 >>**  
**Nissan NV 300 09/2016 >>**





**Partnr.: OP-069-BHU**


- Fitting instructions electric wiring kit tow bar with 12-N socket up to DIN/ISO Norm 1724.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:  
[t.skinner@ecs-electronics.com](mailto:t.skinner@ecs-electronics.com) / 07440 202 052.



# Part list



## ROUTING





## INFO







See Workshop Manual



1




2



3





4






1



5





6









7



8



9





# SOCKET CONNECTION




Pag. 11

10




11




12


1

ECS  
ELECTRONICS





2



3




13







14





15





16



17




18






20 Amp.mini

19




20



TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

## INFO

REINSTALL TRIM.



**User guide**




## INFO

### SOCKET CONNECTION


DIN/ISO 1724	←	🚗	⏏ 1-7	→	☀	STOP	☀
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L
Pmax	21W	2x21W		21W	52W	3x21W	52W
Colour	Yellow	Blue	White	Green	Brown	Red	Black

# UN-243-YZ Reverse lamp pre-wire extension


⚠ MAX = 21W




A




1




2




3



4




5



B

⚠ MAX = 21W



Reverse

