



Renault Megane 11/2008-

Partnr.: RN-078-BHU


- Fitting instructions electric wiring kit tow bar with 12-N socket up to DIN/ISO Norm 1724.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:
t.skinner@ecs-electronics.com / 07440 202 052.




Part list




ROUTING




1




2




3



4




5




A


Option 1



Option 2




Option 3



INFO


SOCKET CONNECTION




Pag. 9

B

Option 1







C

Option 2


1



2




3




D

Option 3


1




2




3





6



7




8






The diagram shows a sequence of numbers in boxes arranged in a staircase pattern. The numbers are: 40, 15, 15, 20, 25, 30, 3, 25, 30, 10, 15, 5, 25, 10, 10, 10, 10, 10, 10, 10. A dashed arrow points from the box containing 15 to the box containing 10.



Remove tape.




+12V	Purple
2,5mm ²	




12


+12V
2,5mm² Purple




1




2




+12V
2,5mm² Purple



3





4




5

13



20 Amp. minifuse

14






TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED’S CANNOT BE USED FOR THIS PURPOSE.

INFO


REINSTALL TRIM.











INFO


SOCKET CONNECTION

DIN/ISO 1724							
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L
Pmax	21W	2x21W		21W	52W	3x21W	52W
Colour	Yellow	Blue	White	Green	Brown	Red	Black





OEM PDC







AFTER MARKET PDC




Option A




Option B



Option C




9 = C
5 = NO
7 = NC




UN-243-YZ Reverse lamp pre-wire extension


⚠ MAX = 21W




A




1




2




3



4



5



B

⚠ MAX = 21W

